

## Appendix L. No Discharge (NODI) Codes

**Instructions:** If no discharge occurs during a monitoring period, a Discharge Monitoring Report (DMR) form must still be submitted in accordance with the “Reporting Requirements” section (Section 7(g)) of the Industrial Stormwater General Permit. The permittee must use the appropriate No Discharge (NODI) code on the DMR from the list below.

NODI Code	NODI Code Description
1	Wrong Flow
2	Operation Shutdown
3	Special Report Attached
4	Discharge to Lagoon/Groundwater
5	Frozen Conditions
6	State-specific No Data Indicator - Invalid
7	No Influent
8	Other (See Comments)
9	Conditional Monitoring - Not Required This Period
A	General Permit Exemption
B	Below Detection Limit/No Detection
C	No Discharge
D	Lost Sample/Data Not Available
E	Failed to Sample/Required Analysis Not Conducted
F	Insufficient Flow for Sampling
G	Sampling Equipment Failure
H	Invalid Test
I	Land Applied
J	Recycled - Water-Closed System
K	Natural Disaster
L	DMR Received but not Entered
M	Laboratory Error
N	Not Constructed
P	Laboratory Error or Invalid Test
Q	Not Quantifiable
R	Administratively Resolved
S	Fire Conditions
T	Environmental Conditions - Monitoring Not Possible
V	Weather Related
W	Dry Lysimeter/Well
X	Parameter/Value Not Reported
Y	State-specific No Data Indicator - Valid