

General Construction Best Management Practices for Sites within a Public Drinking Water Supply Area

DRINKING WATER SECTION • JULY 2014

Emergency Response Plan

A response plan should be written for actions to be taken for the containment of accidental fuel or chemical spills or the failure of temporary erosion and sedimentation controls that may occur during construction. Spill response equipment should be available on-site at all times along with personnel trained in the proper use of such equipment. A person or persons should be designated by the contractor for emergency response coordination on a 24/7 basis.

Vehicles and Machinery

Designate one area for auto parking, vehicle refueling and routine equipment maintenance. The designated area should be well away from exposed surfaces or storm drains. Methods and locations of refueling, servicing, and storage of vehicles and machinery should be addressed and included as notes on the final site plans. Minor servicing and refueling of machinery should be completed on a fueling pad with containment. All major equipment repairs must be made off site. Onsite fuel storage should be discouraged.

General Site Conditions

Keep pollutants off exposed surfaces. The burying of stumps or construction debris must not be allowed on the job site. Sediment fences and hay bales must be strategically placed, inspected and maintained to prevent sedimentation and erosion. Temporary storm water ponds and basins must be routinely inspected and maintained. If unexpected conditions occur, additional fences and hay bales should be available for use as needed to prevent runoff. Protect exposed stockpiles of soil to prevent runoff. Use as little water as possible for dust control. Clean up leaks, drips and other spills immediately to prevent or minimize soil contamination. Never hose down "dirty" pavement or surfaces where materials have spilled. Use dry cleanup methods whenever possible.

Hazardous Materials Storage

Paints, paint products and other hazardous materials should be removed from the site during non-work hours or otherwise stored in a secure area to prevent vandalism. Place covered trashcans and recycling receptacles around the site. Cover and maintain dumpsters, check frequently for leaks, and never clean a dumpster by hosing it down on site.

Sanitation

Make sure portable toilets are in good working order. Check frequently for leaks.

Notification

Notification of the project start date should be sent to the Public Water System as soon as it has been determined. Public Water System personnel should be granted daily site access to review compliance with site best management practices. The Public Water System, DPH Drinking Water Section (860-509-7333 OR after hours at 860-509-8000), and appropriate sections of the Department of Energy and Environmental Protection must be notified immediately of any chemical/fuel spill or any major failure of an erosion and sedimentation control at the construction site. Emergency telephone numbers and a statement identifying the construction site as a sensitive public water supply area should be posted where they are readily visible to contractors and other on-site personnel. A note should be added to the construction documents stating the sensitivity of the area.



Connecticut Department of Public Health Drinking Water Section • 860-509-7333 www.ct.gov/dph/publicdrinkingwater