Connecticut Department of Public Safety Division of Scientific ServicesDocument ID: SOP-FB-06 Revision #: 0

Forensic Laboratory

Revision Date: 01/01/2011
Page 1 of 2

			1 450 1 0	
	Whole Blood Sampling and Preservation Procedure with red stamp present Quality Manager			
Prepared By:		Date:		
Approved By:		Date:		

A. <u>PURPOSE</u>:

To preserve whole blood samples for further analysis.

B. RESPONSIBILITY:

Forensic Science Examiners from the Connecticut State Forensic Science Laboratory who have been trained in the discipline of whole blood sample preservation according to SOP-FB-31 (Training Manual).

C. SAFETY:

Use appropriate measures for the proper handling of a biohazardous material according to SOP-GL-2 (Safety Manual).

D. <u>DEFINITIONS</u>:

- 1. FTA: Fast Technology for Analysis of Nucleic Acids
- 2. EDTA: Ethylenediaminetetraacetic Acid
- 3. PTT: Purple Top Tube
- 4. RTT: Red Top Tube

E. PROCEDURE:

- 1. Materials:
 - a. FTA® Micro cards with provided foil pouches
 - b. Microcentrifuge tubes
 - c. Micropipet and tips
 - d. Wooden sticks
 - e. Desiccant packets
 - f. 20% bleach

2. Procedures:

- a. Record all written information on the appropriate Quality Record Worksheet.
- b. Prior to sample removal:
 - aa. For samples collected in purple top tubes (EDTA) or other tubes containing anticoagulant, thoroughly mix blood.

Connecticut Department of Public Safety Division of Scientific Services Forensic Laboratory

Document ID: SOP-FB-06

Revision #: 0

Revision Date: 01/01/2011

Page 2 of 2

- E. 2. b. bb. For samples collected in red-top tubes (no anticoagulant), break up the blood clot with wooden sticks.
 - c. Remove approximately 125µl of the whole blood with a micropipet and place on a FTA®card, making the stain as concentrated as possible.
 - aa. Label the card with the Laboratory ID#, item #, donor name, date, initials and the type of tube (PTT, RTT).
 - bb. Air dry the bloodstain card overnight in the designated cabinet.
 - cc. After drying, place card in a labeled foil pouch with a desiccant packet and store in the designated room temperature storage area.
 - d. When necessary, aliquot approximately 125µl of whole blood into a labeled microcentrifuge tube and store in freezer.
 - e. Clean the tip of the micropipet after each use with 20% bleach.
 - f. For OCME bloods submitted with additional autopsy samples, refer to the Work Instructions for OCME Autopsy Sample Examination described in SOP-FB-31 (Training Manual).

F. REFERENCES:

- 1. Whatman FTA cards provided Technical and Protocol Information sheet.
- 2. SOP-GL-2 (Safety Manual).