FB SOP-30 M-vac Document ID: 44530

Revision: 3

Effective Date: 05/12/2025

Approved by Director: Dr. Guy Vallaro

Status: Published
Page 1 of 8

#### M-VAC® SAMPLE COLLECTION

#### 30.1 PURPOSE

To provide guidelines for the collection and preservation of samples using the M-Vac® system.

#### A. Theory/Background:

The M-Vac® system is a DNA sample collection method that utilizes wet-vacuum principles to rinse and capture cellular material. A sterile buffer is sprayed onto the surface of an item while a vacuum is created around the dispensed buffer to collect the buffer and dislodged cellular material into a collection bottle. The cellular material is filtered through a disposable filter device and deposited onto a sterile filter for future DNA extraction.

#### B. Limitations:

The spray is approximately 1" in width, and the sample collection head is approximately 1.34" wide. Passes with the collection head should overlap by approximately 30%.

When performing a sample collection, the collection head should only be used in a motion parallel to the handle, not perpendicular.

### **30.2 RESPONSIBILITY**

Personnel qualified to perform Forensic Biology duties.

#### 30.3 SAFETY

Use appropriate measures for the proper handling of biohazardous materials and hazardous chemicals according to GL-2 (Safety Manual).

#### 30.4 DEFINITIONS/ABBREVIATIONS

- 30.4.1 LIMS: Laboratory Information Management System
- 30.4.2 PPE: Personal Protective Equipment
- 30.4.3 QRW(s): Quality Record Worksheet(s); Appendix 1
- 30.4.4 SEC/SEC100: Support Equipment Case
- 30.4.5 SRS: Surface Rinse Solution
- 30.4.6 M-Vac<sup>®</sup>: Microbial Vacuum

FB SOP-30 M-vac Document ID: 44530

Revision: 3

Effective Date: 05/12/2025

Status: Published Page 2 of 8

Approved by Director: Dr. Guy Vallaro

#### 30.5 MATERIALS

A. M-Vac® SEC 100 unit

B. SRS

C. Extension tubing

D. Separation unit

E. Sampling head

F. Tray (glass or metal)

G. Benchkote or other liquid barrier sheets

H. Filter unit

I. Pre-filter

J. Pre-filter vacuum shield

K. Collection bottle

L. Chest harness

M. Scalpel

N. Forceps

O. Scissors

P. Sterile microcentrifuge tubes

#### 30.6 GENERAL NOTES

- 30.6.1 The M-Vac® collection procedure will be performed at the discretion of the examiner, with input from the Unit Lead(s) when applicable, based on the submitting agency requests, case information, and the condition of the evidence.
- 30.6.2. If a body fluid stain or stain portion can be easily cut from the substrate, that is generally the preferred method of sample collection and/or submission to DNA.
- 30.6.3 Refer to FB SOP-01 for instruction on cleaning utensils and laboratory areas, PPE, and for additional instruction on evidence examination including but not limited to documentation, collection, preservation, sterile microcentrifuge tube labeling, verification, sub-itemization, transfers/storage, and LIMS.
- 30.6.4 For additional information and guidance see the SEC 100 User Guide and FB SOP-23 (Equipment Maintenance).

#### 30.7 PROCEDURE

When performing M-Vac® sample collection and filtration, aspects associated with sample collection and containment (including but not limited to collection bottle(s) and filter housing) will be labeled appropriately.

FB SOP-30 M-vac Document ID: 44530

Revision: 3

Effective Date: 05/12/2025

Approved by Director: Dr. Guy Vallaro

Status: Published
Page 3 of 8

### 30.7.1 M-Vac® SEC set-up:

Each port is a point of potential contamination; the handling and connection of any lines and tubing should be performed carefully to avoid touching the exposed ends of the connection points.

- Document the use of the M-Vac® on the appropriate QRW(s) and equipment log sheet(s).
- 30.7.1.2 Clean the exterior housing of the SEC with 10% bleach or stabilized bleach followed by ethanol.
- Remove the SRS from the overwrap and hang the solution bag on the hook on the pressure chamber door.
- 30.7.1.4 Remove the M-Vac® sampling head and separation unit from the overwrap. Tighten the lid of the separation unit (tighten, release, tighten) and place it in the designated holder. Ensure that the switch is pulled back to the off position on the sampling head, and place the sampling head in the designated holder (the configuration of both holders may be adjusted as needed).
- Remove the extension tubing from the overwrap.
  - Attach the solution line fitting to the fitting on the collection unit. Gently attach the vacuum tubing to the port on the collection unit.
  - 30.7.1.5.2 Break off the cover from the SRS port. Push and twist to connect the spiked fitting of the tubing to the bag port. Connect the vacuum side of the tubing to the SEC.
  - 30.7.1.5.3 Extension tubing may be used for multiple sample collections.
- 30.7.1.6 Close the pressure chamber door until it is locked shut by the hinged latch.
- 30.7.1.7 Turn on the SEC.
- Turn on the solution pressurization. The solution is pressurized when the low pressurization indicator light turns off.

#### 30.7.2 Sample collection:

If there could be runoff or pooling of the buffer during the sample collection process, place the item in a clean tray for sample collection.

	OP-30 M-va		Guy Vallaro	Document ID: 44530 Revision: 3 Effective Date: 05/12/2025 Status: Published Page 4 of 8
	30.7.2.1 To		he vacuum switch to on.	
	co th		With the vacuum pump on, retighten the lid of the separation unit. During sample collection, the separation unit should be maintained and/or secured in a manner that ensures it is always upright during sampling (i.e. placed back into the holder on the SEC or placed in the chest harness).	
	th		ace the sampling head against the surface to be sampled so that it is flush with e surface, keeping all flexible feet in light even contact with the surface, as the em permits.	
	30.7.2.4.1 30.7.2.4.2 30.7.2.4.3 30.7.2.4.4		eral, unidirectional multi-pass sampl	ing will be employed:
			The sample spray is turned on whi collection area. The spray is turned	le pulling the sample head over the d off at the end of the stroke.
			Repeat, covering the same area wit least two vacuum only post-spray	th the sample spray off, performing at passes.
			Move the head to the next sample the previous sample area by approx	path, and repeat, attempting to overlap ximately 30%.
			Repeat, until the desired area has b	een sampled.
	30.7.2	2.4.5		nd repeat steps 30.7.2.4.1 – 30.7.2.4.4, minimum of four vacuum only passes
	30.7.2	2.4.6	Collect any pooled or runoff liquid passes as needed.	I from the tray using vacuum only
	30.7.2.6 If the sa		sample area is small, sample until a r	minimum of 30mL has been collected.
			sample area is large, additional collection.	ction bottles may be needed to
	30.7.2	2.6.1	Turn off the vacuum.	
	30.7.2	2.6.2	Unscrew the bottle from the separa	ation unit and cover with a lid.
	30.7.2	2.6.3	Screw a new bottle onto the separa	ation unit.
30.7.3	Removing/rep	olacing th	ne M-Vac® separation unit and sampl	ing head.

## State of Connecticut Department of Emergency Services and Public Protection Division of Scientific Services

FB S	FB SOP-30 M-vac Document ID: 44530					
Аррі	oved by Direc	tor: Dr	. Guy Vallaro	Revision: 3 Effective Date: 05/12/2025 Status: Published Page 5 of 8		
	30.7.3.1	Turn o	off the vacuum and solution pressuriza	ation.		
	30.7.3.2	Unscr	ew the bottle from the separation unit	and cover with a lid.		
	30.7.3.3 If repla		acing with a new separation unit and sampling head:			
	30.7.3.3.1 30.7.3.3.2 30.7.3.3.3		Remove the used separation unit and place it on a clean surface.			
			Clean the holders as appropriate and place the new separation unit and sampling head on the holders.			
			Disconnect extension tubing at the used separation unit and connect to the new separation unit as previously described.			
	30.7.3	.3.4	Properly dispose of the used separate	tion unit and sampling head.		
	30.7.3.4		replacing with a new separation unit, rly dispose of the used separation unit			
30.7.4	Replacing the	acing the SRS				
	30.7.4.1	Turn off the solution pressurization to depressurize the solution pressurization chamber.				
	30.7.4.2	Remo	Remove and discard used SRS.			
	30.7.4.3	Install	the new SRS bag as previously descri	ribed.		
30.7.5	Filtering a sample					
	If the sample a	If the sample appears to contain debris, pre-filtering may be necessary. See 30.7.6.				
	30.7.5.1	Remove the vacuum filter unit from the overwrap. Attach the vacuum tubing to the vacuum filter (the end of the tubing that was previously connected to the separation unit).				
	30.7.5.2	Remove the lid on the filter. Maintain the vacuum filter in an upright position during the filtration process.				
	30.7.5.3	Turn o	on the vacuum.			
	30.7.5.4	Swirl filter.	the sample in the bottle and then slow	ly pour the sample into the vacuum		

Documents outside of the QMS are considered uncontrolled.

FB S	OP-30 M-vac		Document ID: 44530				
Appr	oved by Direct	or: Dr. Guy Vallaro	Revision: 3 Effective Date: 05/12/2025 Status: Published Page 6 of 8				
	30.7.5.5	Continue vacuum pressure until all of the soll fit is taking longer than 20 minutes for the section 30.7.7 below.					
	30.7.5.6	Turn off the vacuum and release the pressure	<u>.</u>				
	30.7.5.7	The filtrate can be used to rinse the collection bottle (1-3 times). Remove the filtrate collection bottle from the bottom of the concentration filter and pour it back into the original sample collection bottle to rinse this bottle. If a pre-filter apparatus was used, it should also be rinsed.					
		If the appropriate sampling head is still connected, it can be used to dispense fresh buffer for rinsing.					
	30.7.5.8	Replace the filtrate collection bottle (if remothrough 30.7.5.6.	ved) and repeat steps 30.7.5.3				
	30.7.5.9	Properly dispose of the filtrate.					
	30.7.5.10	Allow the filter to dry in the filter housing, p	ossibly overnight.				
30.7.6	Pre-filtering san	e-filtering samples					
	30.7.6.1	Remove the pre-filter and vacuum shield fro	m their respective overwrap.				
	30.7.6.2	Attach the vacuum tubing (the end of the tubing that was previously conthe separation unit) to the vacuum shield. The vacuum shield may need replaced during the filtration process if liquid is observed in the shield.					
	30.7.6.3	Connect the pre-filter to the vacuum shield.					
	30.7.6.4	Turn on the vacuum. Maintain the pre-filter the filtration process.	system in an upright position during				
	30.7.6.5	Swirl the sample in the bottle and then slowl	y pour the sample into the pre-filter.				
	30.7.6.6	Continue vacuum pressure until all the soluti the conical (pre-filtration collection) tube ne below.					
	30.7.6.7	Turn off the vacuum and release the pressure	2.				
	30.7.6.8	The conical (pre-filtration collection) tube me throughout the pre-filtration process. Dependent may be poured directly into the vacuu	ling on the overall volume, the				

# State of Connecticut Department of Emergency Services and Public Protection Division of Scientific Services

Documents outside of the QMS are considered uncontrolled.

Revision: 3 Effective Date: 05/12/2025 Approved by Director: Dr. Guy Vallaro Status: Published Page 7 of 8 30.7.6.9 Properly dispose of the used prefilter unit (once rinsed) and vacuum shield. 30.7.7 Filtering slow samples 30.7.7.1 Turn off the vacuum filter (leave the power to the SEC unit on). 30.7.7.2 As the system is sealed, the vacuum pressure will be maintained, and the sample should continue to slowly pass through the filter. When the vacuum has dropped below 16inHg or when the sample has completely 30.7.7.3 filtered, release the vacuum by disconnecting the vacuum hose. 30.7.7.4 Reconnect the vacuum hose and turn the vacuum back on. 30.7.7.5 Repeat until the filtration is complete. If the filtration process appears to have slowed considerably or stopped, 30.7.7.6 additional filter(s) may be used for the remaining sample. If using the filtrate when rinsing the original collection bottle (and other 30.7.7.7 supplies), use a small amount. 30.7.8 Post collection The submission/item will be allowed to dry prior to repackaging. Store/transfer to 30.7.8.1 an appropriate location (such as a hood) while drying overnight. 30.7.8.2 Preparing the filter 30.7.8.1.1 Once dry, excise the filter from the housing using a scalpel and cut in half. Each filter half will be placed into one sterile microcentrifuge tube. 30.7.8.1.2 Properly dispose of the used filter unit. 30.7.9 Filter(s) submitted by an outside agency 30.7.9.1 Cut and prepare filter(s) as described in 30.7.8.2 30.7.9.2 Testing of reddish-brown staining, if observed on a filter, will be determined on a case-by-case basis, based on the information and/or request(s) received with the case. 30.7.10 OC procedure: SRS Buffer

Document ID: 44530

FB SOP-30 M-vac

FB SOP-30 M-vac Document ID: 44530 Revision: 3

Effective Date: 05/12/2025

Approved by Director: Dr. Guy Vallaro

Status: Published
Page 8 of 8

Prior to use with casework samples, a portion of SRS buffer will be provided to the DNA Section for QC purposes according to DNA QR-356 (M-vac Buffer QC).

30.7.10.1 SRS buffer will be dispensed directly into a sterile microcentrifuge tube, using new tubing and a new collection head.

30.7.10.2 If the appropriate results are not obtained, the buffer QC may be repeated with a new bag of the same lot of SRS buffer, new tubing and a new collection head.

30.7.11 Discard/replace buffer and consumables according to the manufacturer's expiration date.

Manufacturer's expiration dates with only the month and year indicated expire the last day of the month indicated.

#### 30.8 REFERENCES

30.8.1 M-Vac® SEC 100 User Guide Rev. J

30.8.2 M-Vac® SEC 100 User Guide Rev. L

30.8.3 GL-2 (Safety Manual)

