

Make sure your electric fence and energizer meet these specifications for success:

- Minimum 0.6-1.0 Joule energizer (output)
- At least 5000V charge on the line
- At least 4 feet high
- At least 5 lines
- No more than 8" between lines
- Bottom line no more than 8" off the
 ground

More tips are on the back

Additional Tips:

- Ensure system is properly grounded. You may need multiple grounding rods.
- Check the voltage every few days and fix problems quickly.
- Keep vegetation cut short under fencing to prevent system from shorting out.
- Keep at least 5 feet of space between fence and what you are protecting. This will keep bears



 Keep fence on and charged year-round, even in winter.

from reaching over.

 Bait hot wires with bacon or peanut butter regularly to encourage mouth/nose contact from bears and ensure they get the shock needed for deterrence.



Additional information is at portal.ct.gov/DEEP-Bears and bearwise.org

Scan this QR Code for the Beginner's Guide to Electric Fencing from BearWise.

