

FUEL MASTER USER INSTRUCTION STEPS

1	<p>Insert Prokee, wait for display to change, then remove Prokee.</p> <p>**FUEL MASTER ACCCOUNTING SYSTEM**</p> <p>**INSERT KEY, HOLD 1 SECOND TO BEGIN**</p>	
2	<p>Enter Odometer/Chronometer reading, (whole numbers only, no tenths) then press "ENTER".</p>	
3	<p>Re-insert Prokee, and hold until display changes.</p>	
4	<p>Remove Prokee, select hose number from those shown, then press "ENTER".</p>	
5	<p>Dispenser is now activated to dispense fuel.</p> <p>**TURN ON PUMP HANDLE TO DISPENSE**</p> <p>**RETURN HOSE AFTER USE**</p>	