







CT DEEP RBV Program Volunteer Field Quick Reference Guide

Step 1: Identify the riffle areas within your stream reach; identify 6 'kick-stop' locations within the study riffle where you will collect your samples.

Step 2: Fill out the top of your datasheet <u>completely</u>. **Use a GPS unit (or Smartphone) to <u>determine the latitude/longitude</u> of your site. **

Step 3: Stand in the middle of the stream and **take a photo facing upstream**. Try to capture as much of the stream and both stream banks as possible in your photograph. Turn 180 degrees and **take a second photo facing downstream**.

Step 4: Place your net, opening facing upstream, at the first kick-stop. Envision an 18 in. (width of the net) by 14 in. rectangle in front of the net (see photo). Pick up any rocks (tennis ball to basket-ball size) located in your imaginary rectangle. One at a time, hold each rock inside the net, under water, and using your hands, rub the rocks briskly to dislodge attached organism. (Imagine you are washing off a dirty softball inside your net.) Set rocks off to the side after washing; take no longer than 2 minutes.

Step 5: Stand next to the net (have your partner hold it), and **use your heel to vigorously 'kick' the stream bottom in front of the net <u>for 1 minute</u> using a back and forth or 'Z' motion to dig up the sediment.**

Step 6: Carefully pick up the net out of the water being careful to not lose any material inside, and move upstream to your second kick-stop. Repeat the process, scrubbing rocks in the net and then kicking the area in front of the net for 1 minute. Empty the net contents from kick 1 and kick 2 into a white sample tray.

Step 7: Repeat Step 4 and 5 at your next two kick-stop locations. Empty the contents of the net into a second white sample tray.

Step 8: Repeat Step 4 and 5 at your last two kick-stop locations. Empty the contents of the net into your third white sample tray.

Step 9: Using tweezers or spoons, pick out as many organisms as possible from each tray; use an ice cube try to sort your organisms into groups of similar looking critters. (There should be one ice cube tray for each sample tray.)

Step 10: Use the RBV Sorting Guide and the Field Identification Cards to try to identify each of the types of organisms in the ice cube trays. As you identify each macroinvertebrate, check the corresponding type as present ("X") on your datasheet.

Step 11: Using your completed datasheet as a guide, place 2-3 of each macroinvertebrate type checked off into a glass or clear plastic voucher container. Complete an RBV label using pencil and place the label *inside* the vial. (You may tape a second label on the outside if you desire.) Fill the container completely with rubbing alcohol and tightly secure the lid in place.

Step 12: Submit the photographs, completed datasheet, and labeled voucher to your Local RBV Coordinator for submission to CT DEEP.



WWW.CT.GOV/DEEP/RBV