

*Approved by Director: Dr. Guy Vallaro***A. Purpose:**

To outline the steps taken to image removable media, submitted to the CCEEL for analysis, while maintaining the integrity of the evidence.

B. Responsibility:

CCEEL forensic examiners

C. Definitions:

Refer to SOP-CC-26 - Definitions and Abbreviations.

D. Procedure:

1. If the removable media consists of optical disks, proceed to SOP-CC-37 - Optical Disk Analysis Protocol.
2. Connect the removable media to a forensic computer using an approved read-only hardware device or software.
3. Connect a staging drive(s) to the forensic computer.
4. Create a folder on the staging drive to image to. Name the folder the specific Laboratory Case Number.
5. Using an approved hashing program (e.g. FTK Imager) and following the procedures outlined in the product manual, obtain the pre-imaging MD5 and/or SHA1 hash values of the removable media prior to imaging. Properly record these values.
6. Make a forensic image of the removable media saving it to the folder created on the staging drive using an approved imaging software program and following the imaging procedures outlined in the product manual.
 - a. If using EnCase to create the image, follow the protocols outlined in the specific Reference Document pertaining to the appropriate EnCase version. Follow the naming conventions outlined in Appendix A - EnCase Naming Conventions when filling in the acquisition information.
 - b. If using FTK Imager to create the image, follow the protocols outlined in the specific Reference Document pertaining to the appropriate FTK Imager version. Follow the naming conventions outlined in Appendix A - FTK Imager Naming Conventions when filling in the acquisition information.
 - c. If using TD1 Forensic Duplicator to create the image, follow the protocols outlined in the specific Reference Document pertaining to the appropriate TD1 Forensic Duplicator version. Follow the naming conventions outlined in Appendix A - TD1 Forensic Duplicator Naming Conventions when filling in the acquisition information.
7. Upon completion, ensure that the pre-imaging hash values and the image hash values match. If the values are identical, remove the removable media and proceed processing the case.
8. In instances when the hash values do not match, follow the following procedures:

Approved by Director: Dr. Guy Vallaro

- a. If read errors and/or bad sectors were encountered in the pre-hash process and/or in the imaging process, document these findings and proceed with processing the case. It is not necessary to attempt the image process again.
- b. If no read errors and/or bad sectors were encountered in the pre-hash process and in the image process, repeat steps 5 and 6. In the event that this process again fails, it is at the examiner's discretion, based on his/her knowledge, training and experience, to determine how to proceed. Document all steps taken at this point and when completed proceed with processing the case.
9. When image processing failure occurs (e.g. does not complete), the image process should be retried using the current imaging software. If the second attempt fails, the imaging process should be performed using another approved imaging device or software.
10. If the third attempt fails, it is at the examiner's discretion, based on his/her training, knowledge and experience, to determine how to proceed. Document all steps taken up to this point.
11. If it is determined that the media cannot be analyzed, the submitting agency should be notified and alternative options should be discussed and documented.
12. Proceed with processing the case.