FA SOP-03 Firearm Safety Check	Document ID: 2865
	Revision: 2

Effective Date: 3/28/2017 Status: Published

Page 1 of 2

A. Purpose:

Approved by Director: Dr. Guy Vallaro

To describe the procedure to render a firearm safe for transfer to the Forensic Biology Unit and/or the Latent Print Unit. Aseptic techniques shall be utilized by the analyst during this safety check. Minimize the amount of handling of the firearm so as to not disturb potential latent fingerprints and/or DNA. If a firearm should reach another unit prior to the safety check, a representative from that unit may contact the Firearms Unit to have this check conducted.

B. Responsibility:

Forensic Science Examiners or other employees assigned to the Unit

C. Procedure:

- 1. The Evidence Receiving Unit shall transfer the evidence to the Firearms Unit representative.
- 2. The Firearms Unit representative shall wear a lab coat, gloves, and a face mask. Additional personal protective equipment (PPE) is located in the supply box under the work table in the back area of the Evidence Receiving Unit.
- 3. Spray the table with stabilized bleach and wipe with a paper towel.
- 4. Spray the table with ethanol and wipe the area with a new paper towel.
- 5. Place a piece of butcher paper over the table top.
- 6. Break the seals on the evidence package and open the container.
 - i. Ensure the firearm is in a safe condition by checking the chamber or cylinder of the gun to ensure there is no live ammunition present.
 - ii. Ensure there is no magazine in the magazine well.
 - iii. Place a zip tie through the action of the firearm if desired.
- 7. Reclose the container and apply evidence tape; initial the seals.
- 8. Stamp the outside of the container with the "Safe" stamp and initial/date the stamp.
- 9. The firearm will be transferred back to the Evidence Receiving personnel and then to the appropriate storage location.
- 10. If the firearm cannot be rendered safe in the Evidence Receiving Unit, the analyst shall transport it to the Firearms Unit for further action.

FA SOP-03 Firearm Safety Check

Document ID: 2865

Revision: 2

Effective Date: 3/28/2017

Status: Published Page 2 of 2

Approved by Director: Dr. Guy Vallaro

i. Once rendered safe in the Firearms Unit, the firearm may be returned to the Evidence Receiving Unit.

D. Equipment:

- 1. PPE (lab coat, mask, gloves)
- 2. Paper towels
- 3. Stabilized bleach solution
- 4. Ethanol
- 5. Butcher paper
- 6. Zip ties (safety straps)
- 7. Additional PPE as needed (hairnets, sleeves, etc.)
- 8. "Safe" stamp, markers, evidence tape

E. References:

- 1. GL2 Safety Manual
- 2. FA SOP-02 General Firearms Safety

