

# NPDES General Permit for the Discharge of Stormwater Associated with Industrial Activities

## Appendix L

### DMR No Data Indicator Codes

#### Purposes:

No Data Indicator Codes (NODI) codes are used on Discharge Monitoring Reports (DMRs) to explain why a specific data value or the DMR cannot be submitted for a given parameter or period. These codes must be used by facilities with NPDES permits to indicate various reasons for missing data, such as operational issues, weather conditions, or sampling failures. Permittees must use the appropriate NODI code on the DMR from the list below.

<u>NODI Code</u>	<u>NODI Code Description</u>
<b>1</b>	<b>Wrong Flow</b>
<b>2</b>	<b>Operation Shutdown</b>
<b>3</b>	<b>Special Report Attached</b>
<b>4</b>	<b>Discharge to Lagoon/Groundwater</b>
<b>5</b>	<b>Frozen Conditions</b>
<b>6</b>	<b>State-specific No Data Indicator – Invalid</b>
<b>7</b>	<b>No Influent</b>
<b>8</b>	<b>Other (See Comments)</b>
<b>9</b>	<b>Conditional Monitoring - Not Required This Period</b>
<b>A</b>	<b>General Permit Exemption</b>
<b>B</b>	<b>Below Detection Limit/No Detection</b>
<b>C</b>	<b>No Discharge</b>
<b>D</b>	<b>Lost Sample/Data Not Available</b>
<b>E</b>	<b>Failed to Sample/Required Analysis Not Conducted</b>
<b>F</b>	<b>Insufficient Flow for Sampling</b>
<b>G</b>	<b>Sampling Equipment Failure</b>
<b>H</b>	<b>Invalid Test</b>
<b>I</b>	<b>Land Applied</b>
<b>J</b>	<b>Recycled - Water-Closed System</b>
<b>K</b>	<b>Natural Disaster</b>
<b>L</b>	<b>DMR Received but not Entered</b>
<b>M</b>	<b>Laboratory Error</b>
<b>N</b>	<b>Not Constructed</b>
<b>P</b>	<b>Laboratory Error or Invalid Test</b>
<b>Q</b>	<b>Not Quantifiable</b>
<b>R</b>	<b>Administratively Resolved</b>
<b>S</b>	<b>Fire Conditions</b>
<b>T</b>	<b>Environmental Conditions - Monitoring Not Possible</b>
<b>V</b>	<b>Weather Related</b>
<b>W</b>	<b>Dry Lysimeter/Well</b>
<b>X</b>	<b>Parameter/Value Not Reported</b>
<b>Y</b>	<b>State-specific No Data Indicator – Valid</b>