**FB SOP-06 Whole Blood Sampling and Preservation** Document ID: 1102

Revision: 1

Effective Date: 8/15/2014

Approved by Director: Dr. Guy Vallaro

Status: Retired Page 1 of 2

### A. PURPOSE:

To preserve whole blood samples for further analysis.

## B. <u>RESPONSIBILITY</u>:

Forensic Science Examiners from the Connecticut State Forensic Science Laboratory who have been trained in the discipline of whole blood sample preservation according to SOP-FB-31 (Training Manual).

# C. SAFETY:

Use appropriate measures for the proper handling of a biohazardous material according to SOP-GL-2 (Safety Manual).

# D. <u>DEFINITIONS</u>:

1. FTA: Fast Technology for Analysis of Nucleic Acids

2. EDTA: Ethylenediaminetetraacetic Acid

3. PTT: Purple Top Tube4. RTT: Red Top Tube

## E. PROCEDURE:

- 1. Materials:
  - a. FTA® Micro cards with provided foil pouches
  - b. Microcentrifuge tubes
  - c. Micropipet and tips
  - d. Wooden sticks
  - e. Desiccant packets
  - f. 20% bleach

#### 2. Procedures:

- a. Record all written information on the appropriate Quality Record Worksheet.
- b. Label the card with the Laboratory ID#, item #, donor name, date, initials of examiner and the type of tube (PTT, RTT).
- E. 2. c. Label the foil pouch with the Laboratory ID#, item #, donor name and type of tube.

FB SOP-06 Whole Blood Sampling and Preservation

Document ID: 1102

Revision: 1

Effective Date: 8/15/2014

Approved by Director: Dr. Guy Vallaro
Status: Retired
Page 2 of 2

d. Prior to sample removal:

aa. For samples collected in purple top tubes (EDTA) or other tubes containing anticoagulant, thoroughly mix blood.

bb. For samples collected in red-top tubes (no anticoagulant), break up the blood clot with wooden sticks.

- e. Remove approximately 125µl of the whole blood with a micropipet and place on an FTA® card, making the stain as concentrated as possible.
  - aa. Air dry the bloodstain card in the designated cabinet.
  - bb. Clean the micropipet after each use with 20% bleach.
  - cc. After drying, place the card in the labeled foil pouch with a desiccant packet. Seal the pouch and initial the seal.
- f. Create the bloodstain in LIMS and print out a barcode. Place the barcode on the pouch. Transfer and store the bloodstain in the "FTA Blood Storage" location.
- g. When necessary, aliquot approximately 125µl of whole blood into a labeled microcentrifuge tube, create in LIMS and store in the freezer.
- h. For OCME bloods submitted with additional autopsy samples, refer to the Work Instructions for OCME Autopsy Sample Examination described in SOP-FB-31 (Training Manual).

### F. <u>REFERENCES</u>:

- 1. Whatman FTA cards provided Technical and Protocol Information sheet.
- 2. SOP-GL-2 (Safety Manual).